

## Directions for installing the Laborie Graphite Endpin

It is essential to have the right tools!

The conicity of the plug is 1/17

1. Drill a 12mm hole at the precise place (about 22mm from the back) and at the exact angle ( $44^\circ$ ) to the rib. Drill parallel to a steel bent endpin as a guide.
2. Use a cello peg reamer as a pilot to enlarge the hole.
3. Enlarge the hole with a cello endpin reamer. The Dick-Herdim tool is perfect for that: cone 1/17, Diameters 27.5 x 15mm, length 212.5mm. Catalogue item #730701.
4. Leave 2-3mm gap between the plug edge and the rib.
5. Adjust the length of the carbon bar and put the rubber on.

Do not reduce (reshape) the diameter of the plug.



9100 Louis Avenue  
Silver Spring, MD 20910  
tel/fax: 301-588-9275  
[www.slavapub.net](http://www.slavapub.net)